Stay in control of your access.

ROSSLARE

AxTraxNG software, level 0 (free): 1 to 256 readers

SCAP part number: AX-NG-L0

Windows client/server software for managing Rosslare networked controllers, from 2 doors to several thousand. Free up to 256 readers with Rosslare panels.



Technical specifications

Publisher	Rosslare Security Products
Controllers	AC-215x, AC-215xB, AC-225x, AC-225xB, AC-425x, AC-425xB and AC-825IP
Readers	1 to 256
Client workstations	Up to 40 simultaneously (LAN or WAN)
Functions	Badge designer, time zones, user and access groups, automation, e-mail notifications, controller updates, interactive site map, event log and reports, database backup and restore

Commercial information

SCAP part number	AX-NG-L0
Brand	ROSSLARE – AxTraxPro / AxTraxNG software
Family	ROSSLARE brand: access control
Description	AxTraxNG software, level 0 (free): 1 to 256 readers
Delivery	Constant stock; next-day or two-day delivery depending on availability. Lead times are given for guidance only.
Free carriage threshold	For any order delivered in a single shipment with a minimum value of €1,000 excl. VAT (excluding carriage).
Minimum order	€100 excl. VAT. Below that: payment in advance or a €15 excl. VAT handling charge.
Payment	First order paid in advance when the account is opened, then 30 days end of month once credit insurance is approved.
Warranty	12 months from the invoice date (return for replacement or repair of the faulty part).
Complaints	Visible defects: reservations within 2 clear days of receipt. Quantities and quality: 8 clear days.
Returns	Only with prior written agreement, within one month of delivery; credit note issued on the basis of 90% of the invoiced amount.

Indicative specifications, subject to change without notice. Prices and availability: contact SCAP.